

# Model: SF-102 Digital Temperature Controller



Dimension:77(Length)×35(Width)×60(Depth)mm  
 Mounting hole dimension:71(Length)×29(Width)mm

## Features of Function

- Mini-sized and integrated intelligent control and applicable to the compressor of one HP.
- Temperature Display(celsius/Fahrenheit degree switcheble)/ Temperature Control / Manual, automatic defrost by turning off compressor / Light Control /Time/Temp. Setting to end defrosting/Value Storing/ Self Testing /Parameter Locking

## Specifications

1. Output of the outside sealed transformer:AC12V(one transformer matched with one temp. controller)
2. Temperature sensor: NTC, Double sensors(for cold room temp.&defrost control),2m(L)
3. Range of temperature displayed : -45~66°C (-45~150°F); Accuracy:± 1°C(±2°F)
4. Range of set temperature: -45~45°C (-45~120°F); Factory default :0°C (32°F)
5. Temperature of the operating environment: -10~60°C(14~140°F)  
Relative Humidity:20%~90%(Non-condensing)
6. Relay output contact capacity:
  - Compressor relay: N.O. 20A/250VAC  
(applicable to 1 HP Compressor,if more it needs an connect AC contactor)
  - Light relay: N.O.5A/250VAC

## Front Panel Operation

1. Set temperature (compressor stop temperature) adjustment
  - Press **SET** button, the set temperature is displayed.
  - Press **▲** or **▼** button to modify and store the displayed value. Press **SET** button to exit the adjustment and display the cold room temperature.
  - If no more button is pressed within 6 seconds, the cold room temperature will be displayed.  
(Set temperature adjustment range: parameter E1~E2)
2. Light: Press **Light** button, it lights; Press again, it stops.
3. Manual start/stop defrost: Press **Defrost** button and hold for 6 seconds to defrost or stop defrost.
4. Display the evap. Temperature : Press **▲** button and hold for 6 seconds, the evap. Temp. is displayed., After 6 seconds the cold room temp. is resumed to be displayed.
5. Refrigeration LED:During refrigeration,the LED is on;When the cold room temp. is constant,the LED is off; During the delay start, the LED flashes.
6. Defrost LED: during defrosting, the LED is on; During the delay display of defrost, the LED flashes.
7. Parameter setup
  - Press **SET** button and hold for 6 seconds to enter the parameter setup mode while E1 flashes.
  - Press again **SET** button to select sequentially from the parameters : E1,E2,E3,E4,E5,E6,F1,F2~F4,C1.
  - Press **▲** or **▼** button, the value of parameter will be displayed and can be modified and stored.
  - If no more button is pressed within 6 seconds, the cold room temperature will be displayed.

Parameter	Function	Set range	Default	Parameter	Function	Set range	Default
E1	Lower setpoint limit	-45°F ~ Set temp. -45°C	-31°F -35°C	F1	Max. Defrost duration	1~60Min	20Min
E2	Higher setpoint limit	Set temp.~ 120°F 45°C	68°F 20°C	F2	Defrost interval time	0~24Hr	6Hr
E3	Temp. Hysteresis	1~18 °F 1~10°C	7 °F 4°C	F3	Defrost termination temp.	32~68 °F 0~20°C	46°F 8°C
E4	Comp.start delay time	0~10Min	2Min	F4	Display during defrost	0=Normal display 1=Last value before defrost	0
E5	Offset on room temp.	-36~36°F -20~20°C	0	C1	Temperature unit	°C=Celsius °F= Fahrenheit	°C
E6	Offset on evap. Temp.	-36~36°F -20~20°C	0				

8. Factory default revision: Press **SET** button to adjust set temperature well. Press **SET** button for 6 seconds to enter parameter setup mode to set the parameter and then press **SET** button again for 6 seconds, "COP" will be displayed, the stored and revised set temperature and parameter are factory default.
9. The factory default resumption: press **▽** button and **△** button simultaneously for 6 seconds, "888" flashes, all parameters will be resumed as same as factory defaults. After 6 seconds, it returns to normal operation.
10. Lock parameters  
In normal operating, press **▽** button and hold for 6 seconds to lock the parameters if "OFF" is displayed (No modification is allowed), or to unlock if "ON" is displayed. Parameter can be displayed only and can not be modified if locked, but the adjustment of the set temp. is active. (the factory default is "ON" )

### Function details

#### 1. Temperature Control

- After turning on for the delay time, the compressor starts operating when cold room temperature  $\geq$  (set temperature + hysteresis), and will be off when cold room temperature  $\leq$  set temperature.
- To protect the compressor, it can not re-start unless the time when the compressor stops every time is longer than the delay time (Parameter E4).

#### 2. Defrost

- It defrosts only if the temp. of the evap. sensor is less than the defrost termination temp. (Parameter F3).
- Operating after a defrost interval time it will be automatically in the status of defrost. If the temperature of evap. sensor is less than the defrost termination temperature, the defrost LED will turn on, and the compressor will stop.
- When the temp. of the evap. sensor is over the temp. of defrost termination; or the defrost duration ends, the compressor will exit the defrost status and enter the normal status of refrigeration. When cold-room temperature  $>$  (set temperature + temp. Hysteresis), the compressor will start.
- When the defrost interval time is set to "00", the function of automatic defrost will be cancelled.

#### 3. Display during defrost

When setting the parameter F4=1, the room temp. is locked during defrost, and the last value before defrost is displayed. When defrost ends, normal display will be resumed after 20 minutes delay of room temp. display. The defrost LED flashes during the delay.

#### 4. Abnormal work mode

- When room sensor is short-circuited or overheated (more than  $66^{\circ}\text{C}/150^{\circ}\text{F}$ ) "HH" is displayed; when room sensor is open-circuited or temperature is too low (less than  $-45^{\circ}\text{C}/-45^{\circ}\text{F}$ ) "LL" is displayed. At that time the compressor work automatically by the cycle of 30 minutes on and 15 minutes off.
- When evap. sensor fails or over the displayed range, the defrost termination will be just controlled by the defrost duration. (Parameter F1)

### Notes for Installation

1. Sensor leads must be kept separately from main voltage wires in order to avoid high frequency noise induced. Separate the power supply of the loads from the power supply of the controller.
2. When installation the sensor shall be placed with the head upward and the wire downward; The evaporator sensor must be installed between the fins of the evaporator in the area, where probably the ice is the thickest.
3. In case of long-distance probe installation from the controller, the probe cable may be prolonged up to 100 m max. without any re-calibration
4. The temperature controller can not be installed in the area with water drops.

### Accessories for the temperature controller

1. One attached transformer
2. Two temperature sensors
3. One installation stand
4. One cover panel and 1  $\phi$  3  $\times$  10mm screw

### Circuit Diagram

